NC Department of Insurance Office of the State Fire Marshal - Engineering Division 1202 Mail Service Center, Raleigh, NC 27699-1202 919-661-5880

Definition of Residential Basement Wall And Above Grade Wall

Code: 2012 Energy Conservation Code **Date:** July 3, 2012

Section: 202

Question:

For low-rise residential buildings, when is a wall considered a "basement wall" rather than an "above grade wall"?

Answer:

Per the definition in Section 202, a residential building "basement wall" is:

A wall 50% or more below grade and enclosing conditioned space.

Note that a below-grade wall having an average below-grade area less than fifty per cent of its total wall area is considered an "above grade wall".

Table 402.1.1 contains distinct separate R-value requirements for above grade walls and basement walls.